

Rinse Aid With Built In Descaler

DESCRIPTION & BENEFITS

Rinse Aid with Built In Descaler is a clear blue liquid with no odour. It has additional features of a built-in descaler to our conventional Rinse Aid which not only eliminates water spotting on glassware, crockery and cutlery but also protects the dishwasher/glasswasher from rusting or scaling from food deposits. It is also designed to help disperse the rinse water to ensure the rapid drying of dishes and utensils. This product is suitable for all water conditions, simple and safe to use.

Rinse Aid with Built In Descaler has an advanced formula that eliminates the possibility of scale formation within the washing machine ensuring an excellent performance. It is ideally suited for use in all commercial and automatic warewashing machines.

- ✓ Built-in descaler
- ✓ Works in hard or soft water
- ✓ Leaves glasses sparkling & streak free
- ✓ Economical formula

DIRECTIONS FOR USE

Machine with no Automatic Rinse & Dispenser:

Add ½ - ¼ teaspoon to the final rinse.

Machine with Automatic Rinse & Dispenser:

Refer to your machine instruction booklet. Check dispenser regularly.



Code No 143

ENVIRONMENTAL ASPECTS

- ✓ PF - Phosphate Free
- ✓ Biodegradable Surfactants
- ✓ Safe for food processing areas & septic tanks when used according to directions provided

PRODUCT AVAILABILITY

This product is available in 20L, 15L, 5L.

SAFETY INFORMATION

Consult us for specific use directions and SDS. For service and additional information please contact us on **1800 201 700**.