

## Rinse Aid

### DESCRIPTION & BENEFITS

**Rinse Aid** is a clear blue liquid with no odour. Rinse Aid has been specially formulated to eliminate water spotting on glassware, crockery and cutlery. It is also designed to help disperse the rinse water to ensure the rapid drying of dishes and utensils. This product is suitable for all water conditions, simple and safe to use.

**Rinse Aid** has an advanced formula that eliminates the possibility of scale formation within the washing machine ensuring an excellent performance. Rinse Aid is ideally suited for use in all commercial and automatic warewashing machines.

- ✓ Fresh Works in hard or soft water
- ✓ Leaves glasses sparkling & streak free
- ✓ Economical formula

### DIRECTIONS FOR USE

**Machine with no Automatic Rinse & Dispenser:** Add ½ - ¼ teaspoon to the final rinse

**Machine with Automatic Rinse & Dispenser:** Refer to your machine instruction booklet. Check dispenser regularly.



**Code No 140**

### ENVIROMENTAL ASPECTS

- ✓ PF- Phosphate Free
- ✓ Biodegradable Surfactants
- ✓ Safe for food processing areas & Septic tanks when used according to directions provided

### PRODUCT AVAILABILITY

This product is available in 20L, 15L, 5L.

### SAFETY INFORMATION

Consult us for specific use directions and SDS. For service and additional information please contact us on **1800 201 700**.